

Unverbindliche Einbauempfehlung. GRAMMER übernimmt keine Haftung für die Eignung des Sitzes zum Einbau in bestimmte Fahrzeuge.


Vor der Verwendung ist die individuelle Einbausituation zu prüfen. Masszeichnungen sind auf Anfrage verfügbar.

Die gesetzlichen und versicherungstechnischen Vorschriften sind zu beachten.

Non-binding installation recommendation, no responsibility is taken for suitability of the driver seat for installation in certain vehicles.

Before ordering, the individual installation situation in each case should be checked. Dimensional drawings are available on request.

Attention should be paid to the relevant legal and insurance requirements.

Fendt		<div style="display: flex; justify-content: space-between; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);"> MSG95EAC/741 MSG95EL/741 MSG95AL/741 MSG95AL/731 MSG95A/731 MSG95G/731 MSG85/721 MSG83/511 MSG83/521 MSG83/721 MSG93/511 MSG93/521 MSG93/721 MSG75GL/511 MSG75GL/521 MSG44/520 MSG44/520 DS44/1B </div> <div style="text-align: center;">  </div> </div>															Zurück zur Übersicht Back to overview				
		Maximo Evol.Active Maximo Evol.Dynamic Maximo Dynamic Maximo Professional Maximo Comfort Plus Maximo Comfort Maximo Basic Compacto Basic S Compacto Basic M Compacto Basic W Compacto Comfort S Compacto Comfort M Compacto Comfort W Primo Professional S Primo Professional M Universo Basic Universo Basic Plus Vario																			
Modell	Type	Nachrüststz / Aftermarket seat type															Bemerkung / Remarks				
Traktor/tractor																					
Farmer 100	102							X	X			X	X					X	X	X	
Farmer 100	102LS							X	X			X	X					X	X	X	
Farmer 100	102S							X	X			X	X					X	X	X	
Farmer 100	103							X	X			X	X					X	X	X	
Farmer 100	103LS							X	X			X	X					X	X	X	
Farmer 100	103S							X	X			X	X					X	X	X	
Farmer 100	104							X	X			X	X					X	X	X	
Farmer 100	104LS							X	X			X	X					X	X	X	
Farmer 100	104S							X	X			X	X					X	X	X	
Farmer 100	105							X	X			X	X					X	X	X	
Farmer 100	105LS							X	X			X	X					X	X	X	
Farmer 100	105S							X	X			X	X					X	X	X	
Farmer 100	106							X	X			X	X					X	X	X	

Farmer 100	106LS								X	X		X	X			X	X	X	
Farmer 100	106S								X	X		X	X			X	X	X	
Farmer 100	108								X	X		X	X			X	X	X	
Farmer 100	108LS								X	X		X	X			X	X	X	
Farmer 100	108S								X	X		X	X			X	X	X	
Farmer 200	200S								X	X		X	X			X	X	X	
Farmer 200	200V								X			X							
Farmer 200	201S								X	X		X	X			X	X	X	
Farmer 200	203P								X			X							
Farmer 200	203V								X			X							
Farmer 200	204P								X	X		X	X			X	X	X	
Farmer 200	205								X	X		X	X			X	X	X	
Farmer 200	206								X	X		X	X			X	X		
Farmer 200	207								X	X		X	X			X	X		
Farmer 200	208								X	X		X	X			X	X		
Farmer 200	209								X	X		X	X			X	X		
Farmer 200	240								X	X		X	X			X	X	X	
Farmer 200	240S								X	X		X	X			X	X	X	
Farmer 200	250S								X	X		X	X			X	X	X	
Farmer 200	250V								X	X		X	X			X	X	X	
Farmer 200	258S								X	X		X	X			X	X	X	
Farmer 200	260P								X	X		X	X			X	X	X	
Farmer 200	260PA								X	X		X	X			X	X	X	
Farmer 200	260S								X	X		X	X			X	X	X	
Farmer 200	260V								X	X		X	X			X	X	X	
Farmer 200	260VA								X	X		X	X			X	X	X	
Farmer 200	270P								X	X		X	X			X	X	X	
Farmer 200	270PA								X	X		X	X			X	X	X	
Farmer 200	270V								X	X		X	X			X	X	X	
Farmer 200	270VA								X	X		X	X			X	X	X	
Farmer 200	275S								X	X		X	X			X	X	X	
Farmer 200	275SA								X	X		X	X			X	X	X	
Farmer 200	275V								X	X		X	X			X	X	X	
Farmer 200	280P								X	X		X	X			X	X	X	
Farmer 200	280PA								X	X		X	X			X	X	X	
Farmer 200	280S								X	X		X	X			X	X	X	
Farmer 200	280SA								X	X		X	X			X	X	X	

